

ARDEX TLT™ SHOWER SYSTEMS

Bond Drain Flange with Mortar Bed Installation Guide

- Install ARDEX TLT™ Building Panels per specific installation instructions.
- Install ARDEX Square Drain Kit per specific installation instructions.
- Adhere the ARDEX TLT™ Bond Drain Flange assembly with ARDEX CA 20 P™.
- Create a level perimeter with ARDEX A 38™ mortar mix that is 1/4" per foot higher than the bonded drain flange assembly. Every linear foot needs a 1/4" rise, example 3 feet will need 3/4" rise etc.
- Fill in-between the bonded drain flange and the level perimeter with additional ARDEX A 38™ mortar mix. This will then be screeded to create slope to the drain.
- Once allowed to fully cure, cover with the recommended waterproofing membrane, being sure to overlap it onto the bonded drain flange.



tile & stone
Installation Systems

www.ardexamericas.com

BUILT BY
YOU
backed by **ARDEX**